

ErgoLite 6028

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos


Reservdelar

A ErgoLite 6028
STARTER




Page A		ErgoLite 6028		Starter	
Position	Article	Quantity	Notes	Kit	
1	576 63 76-01	1			
2	577 27 16-01	1			1
3	576 63 77-01	1			1
4	575 89 64-01	1			1
5	574 28 69-02	1			1
6	523 01 07-01	1			1
7	523 01 10-01	1			1
8	523 01 12-01	1			1
9	577 22 61-03	1			1
10	504 08 80-01	4			
11	578 90 94-02	1			

B ErgoLite 6028
CYLINDER COVER




Position	Article	Quantity	Notes	Kit
1	576 64 25-01	1		
2	504 08 80-01	2		
3	576 63 82-01	1		
4	575 43 46-01	2		3

C ErgoLite 6028
CARBURETOR & AIRFILTER




Position	Article	Quantity	Notes	Kit
1	578 90 95-01	1		
2	537 21 32-02	1		
3	576 64 31-01	1		
4	523 01 34-01	1		
5	573 92 58-02	2		
6	523 01 25-01	1		
7	523 01 27-02	1		
8	544 10 58-02	2		7
9	544 10 58-03	1		7
10	731 23 14-01	1		7
11	523 01 24-01	1		
12	525 54 85-01	1		
13	574 44 40-02	2		
14	576 27 75-02	1		
15	525 76 09-04	4		
16	525 74 17-02	1		
17	522 91 13-01	4		16
18	522 91 85-01	1		

D ErgoLite 6028
FUEL TANK




Page D		ErgoLite 6028		Fuel tank	
Position	Article	Quantity	Notes	Kit	
1	523 01 42-03	1			
2	544 10 58-02	2		1	
3	574 60 39-01	1		1	
4	544 32 50-02	1	300mm	1	
5	575 55 38-01	1		1	
6	574 60 02-01	1	150mm	1	
7	504 11 32-03	1			
8	525 82 20-01	2			
9	525 75 51-01	2			
10	537 18 49-01	1		1	

E ErgoLite 6028
IGNITION SYSTEM




Page E		ErgoLite 6028		Ignition system	
Position	Article	Quantity	Notes	Kit	
1	525 73 95-01	1			
2	525 63 71-01	2			1
3	573 95 15-01	2			1
4	735 58 30-00	2			1
5	731 71 16-51	1			
6	503 23 54-01	1			
7	525 75 51-01	2			
8	525 87 33-01	1			
9	501 48 56-01	1			8
10	577 57 25-01	1			8

F ErgoLite 6028
MUFFLER




Page F		ErgoLite 6028		Muffler	
Position	Article	Quantity	Notes	Kit	
1	523 03 26-01	1			
2	525 74 16-01	1			1
3	504 08 79-01	1			1
4	522 99 73-01	1			
5	525 75 51-01	2			

G ErgoLite 6028
CYLINDER & PISTON




Position	Article	Quantity	Notes	Kit
1	577 38 03-01	1		
2	510 22 36-02	1		1
3	737 44 08-00	2		1,2
4	525 57 77-01	2		1,2
5	505 15 58-01	1		1,2
6	575 50 49-01	1		1,2
7	525 82 50-01	2		
8	525 52 21-01	1		
9	523 01 35-01	1		

H ErgoLite 6028
CRANKCASE




Page H		ErgoLite 6028		Crankcase	
Position	Article	Quantity	Notes	Kit	
1	577 66 99-01	1			
2	525 86 38-01	2			1
3	525 63 73-01	2			1
4	735 31 27-10	2			1
5	525 82 50-01	3			1
6	525 72 84-01	2			1
7	525 52 19-01	1			1

J ErgoLite 6028
CRANK SHAFT



Page J		ErgoLite 6028		Crankshaft	
Position	Article	Quantity	Notes	Kit	
1	577 67 00-01	1			
2	575 50 49-01	1			1
3	525 63 73-01	2			1
4	525 72 84-01	2			1

K ErgoLite 6028 HANDLE




WARNING!
 Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

15 (US)


Page K		ErgoLite 6028		Handle	
Position	Article	Quantity	Notes	Kit	
1	576 64 35-01	1			
2	504 08 97-03	1			
3	504 08 94-03	1			
4	504 08 96-01	1			
5	576 64 34-01	1			
6	537 41 90-01	1			
7	574 48 88-02	1			
8	575 57 21-01	1			
9	523 01 54-02	1			
10	573 92 58-01	6			
11	525 63 35-01	4			
12	525 63 37-01	2			
13	734 18 14-55	4			
14	544 21 84-05	2			
15	575 95 65-02	1	US		
16	544 21 84-03	2			
17	525 63 36-01	4			
18	525 63 38-01	2			
19	576 64 32-01	1			
20	575 23 20-02	1			
21	576 64 36-02	1			
22	504 08 98-01	1			

L ErgoLite 6028
CLUTCH & GEARBOX







Page L		ErgoLite 6028		Clutch & gearbox	
Position	Article	Quantity	Notes	Kit	
1	577 64 76-01	1			
2	738 21 01-04	2			1
3	525 52 81-01	1			1
4	506 44 93-01	1			1
5	504 08 47-01	1			
6	525 52 84-01	1			
7	544 21 84-03	3			
8	575 65 99-01	1			
9	523 01 36-01	1			
10	525 75 51-01	1			
11	525 52 82-01	2			
12	525 52 89-01	1			
13	525 52 87-01	2			
14	525 52 88-01	1			
15	525 52 90-01	1			
16	525 52 83-01	1			
17	525 75 51-01	6			
18	575 48 41-01	1			

M ErgoLite 6028
CUTTING EQUIPMENT



Page M		ErgoLite 6028		Cutting equipment	
Position	Article	Quantity	Notes	Kit	
1	731 71 14-51	2			
2	731 23 14-01	6			
3	525 35 08-01	1			
4	525 35 16-01	1			
5	577 27 19-01	2			
6	525 35 11-01	1			
7	525 35 19-01	8			
8	525 75 51-05	6			
9	525 35 20-01	1			
10	525 75 51-03	2			
11	577 26 88-02	1			

N ErgoLite 6028
ACCESSORIES



Page N		ErgoLite 6028		Accessories	
Position	Article	Quantity	Notes	Kit	
1	577 50 12-01	1			
2	577 76 56-01	1			1
3	575 73 82-01	1			1
8	544 14 22-01	1	UL22		
9	544 14 21-01	1	UL21		
10	531 00 92-05	1	Slick 50 Cartridge 400gr		